

# SET UP YOUR DEVICE IN 5 STEPS

**IMPORTANT: ACTIVEPURE CELLS MUST BE TURNED ON TO PROTECT YOUR ENVIRONMENT FROM PATHOGENS**

## 1 PLUG IN MACHINE

you'll hear a beep and the front panel will light up for a second.

## 2 TURN ON DEVICE

Push LEFT most button once.

## 3 TURN ON ACTIVEPURE

Push RIGHT most button once to turn on first cell (protects small space and/or for low occupancy), push twice to turn on both cells (large space and/or for high occupancy, over 10 people).

## 4 LOOK inside the machine from the top,

**MAKE SURE BLUE LIGHTS ARE GLOWING!**

Contact us if blue lights aren't turning on.


## 5 ADJUST FAN SPEED

Start on full speed for a few hours to fill the room, then turn down to desired level.

### SAFE AIR NOW™ WARRANTY

MACHINE/POWER SUPPLY: 90 days. NEW CELLS: 1yr  
We will replace/repair any Vollara/Airus/Air Scrubber brand unit, supplies pending.  
After 90 days we offer flexible repair options.  
Contact us at [air@safeairnow.com](mailto:air@safeairnow.com)

## AIR & SURFACEPRO



  
**SafeAirNow**

AIR & SURFACE SANITATION EQUIPMENT  
*Safer spaces for everyday wellness*

541-393-9080 ■ [SafeAirNow.com](https://SafeAirNow.com)

cleaning/maintenance  
instructions ►

# CLEANING & MAINTENANCE

## MONTHLY OR WHEN CLEANING LIGHT IS ON:

### Clean the Pre-Filter Assembly

Cleaning video:



- Remove the rear panel by pressing top two spots.
- Remove filter from the unit. You may need to unscrew tiny top screw. Certified Pre-owned machines may already have the screw in the machine frame, not over the filter. Use a hand-held vacuum to remove particulate and/or blow compressed air through it.
- If the unit looks fairly clean, vacuum/use compressed air to clean the ActivePure® Cells from the outside and use rag and very gentle cleaner or sanitizing wet wipe to remove dust.
- If machine looks dusty inside, remove the ActivePure® Cells and carefully vacuum/use compressed air to remove accumulated lint from the honeycomb. To remove cells: unscrew the two gold knobs, push on top of the plug on right side and pull the plug out. Gently pull the cell toward you. See page 10 of your manual for more info on cell removal.

NOTE: Do not wash the ActivePure® Cells as water will damage them.

- Vacuum and wipe top and rear grill openings.

If the machine's fan looks dusty, for example if you were using it during construction and there's drywall dust on it, use a regular phillips screw driver to remove two screws that hold the top grill, gently remove it and wipe the top of the fan blades / the well with a damp rag.

NOTE: Be sure to press the reminder RESET button on front panel to clear the reminder light following regular maintenance.

## YEARLY MAINTENANCE:

MORE VIDEOS ON  
CLEANING AND  
MAINTENANCE:



### Pre-Filter

If the Filter can't be cleaned by vacuuming or running compressed air thru it, replace it. Replace filter after an air event such as very heavy smoke. You may take the filter apart, wash, dry, reassemble.

### Cells

If a cell goes bad (won't turn on or light flickering/barely there/yellow-green, you should troubleshoot first, and if it's damaged or burnt out, replace the cell.

NOTE: The ActivePure® Cells should be replaced every 1-2 years for best performance. You can purchase replacement parts by contacting the rep who sold you the equipment. After a year of use, the cell light will be blinking on the front of the machine, it's a reminder for you to change the cell! Swap out both cells, plug in unit (do NOT turn on) and push RESET button till it beeps, that'll reset the machine for another yearly cell check reminder.